

OFFICE CHAIR

ASSEMBLY INSTRUCTIONS


GGIN0208BK-1FOUR/GGIN0208BN-1FOUR



ATTENTION

Thanks for choosing our product.

1. Please check the manual carefully and make sure you have received all the parts.
2. If there is any missing part, please let us know the letter of the parts you need.
3. If there is any damage part, please send clear photos to us, we will check and offer you best solution soon.



Introduction to Key Functions:

1. ① BUTTON: TAP THE ON / OFF DEVICE;
2. ▲ BUTTON: MESSAGE MODE SELECTION CAN BE SWITCHED TO CHOOSE 8 MESSAGE MODES
3. 🔊 BUTTON: POWER ON, PRESS ON THE HEATING FUNCTION, AND PRESS OFF THE HEATING FUNCTION AGAIN;
4. ✕ BUTTON: MESSAGE INTENSITY ADJUSTMENT-GRADUALLY ENHANCED (3 GEAR ADJUSTMENT LOW, MEDIUM AND HIGH);
5. / BUTTON: MESSAGE INTENSITY ADJUSTMENT-GRADUALLY WEAKENED (3 GEAR ADJUSTMENT HIGH, MEDIUM AND LOW);
6. •🔊 BUTTON: MESSAGE SITE SWITCHING SELECTION (3 SITES SWITCHING).

NOTES: 1. Message red indicator light 1-8, select the message mode to display the corresponding indicator light on;











2. Green indicator light for the message area, Choose the message site The corresponding indicator light is flashing;

3. Strength red indicator light 1-3, When adjusting the message intensity, the red indicator light displays the corresponding intensity light, When the message intensity adjustment is stopped, After 5 seconds, The indicator light will display the message mode indicator light status;

4. Open the heating, The red indicator light is on, Because the heating belongs to an independent function, When the hand control open key is closed, The heating function is not affected, Need to self, open / close,

Assembly Instruction

Parts List

A 	B 	C 	D 	E 	G 
5 pcs	5 pcs	1 pc	1 pc	1 pc	1 pc
H 	I 	J 	K  M6*15mm	L  M6*30mm	M  M8*25mm
1 pc	1 pc	2 pcs	10 pcs	4 pcs	3 pcs
N  M8*35mm	O 	P 	Q 	R 	
4 pcs	4 pcs	1 pc	1 pc	1 pc	

Please note: Please check carefully if there are any missing parts before installation. If there are any missing parts, please place all the parts and take pictures then tell us the missing part number. We will reply you as soon as possible.


Assembly Instruction

Chair Assembly

Step 1

A*5

K*10



First, we need to prepare the connector (C), 5* metal feet (B), 5* universal wheels (A), 10*15mm screws (K) and a wrench (R). Then, according to the figure, insert the 5* metal feet into the connector, align the screw holes, install the screws and tighten them. Finally, a universal wheel is installed on the tail of each metal foot.

WARRANTY

So glad you have completed the assembly and can enjoy it.

If you are satisfied with our products, thank you for showing it to your around.

Our products come with a 12-month warranty, please register within 30 days by send “ your name + order ID” to

info@homrest.com

AFTER-SALE POLICY

For return reason:

Wrong purchase, bought by mistake, no longer needed, doesn't meet expectation, a size smaller than expectation, customer need to cover the return shipping fee.

For cancel order:

Customer needs to pay for shipping fee and carrier handle fee if the item has been shipped out.

For change address: customer needs to pay for extra shipping fee and carrier handle fee if the item has been shipped out.

Customer Service:

Any problem with the product or shipping issue, please feel free to contact us, we will try our best to serve and help.

Assembly Instruction

Chair Assembly

Step 8




Assembly Instruction

Chair Assembly


Step 2

D*1
E*1



Step 3

L*4
I*1




As shown in the figure, insert the connecting piece 'I' into the interface at the bottom of the backrest and fix it with 4 screws numbered 'L'.

Assembly Instruction

Chair Assembly

Step 4

M*3




As shown in the figure, insert the other end of the connecting piece 'I' into the interface behind the cushion and fix it with 3 screws numbered 'M'.

Step 5

J*2

N*4


O*4



Assembly Instruction

Chair Assembly

Step 6



Step 7

P*1

Q*1

