

OFFICE CHAIR

ASSEMBLY INSTRUCTIONS

KRTJHM023



Assembly Instruction


Parts List

A*5	B*5	C*1	D*1	E*1	F*1
					
Casters	Base feet	Base frame	Gas lift rod	Mechanism	Backrest
G*1	H*1	I*1	J*4	K*4	L*4
					
Seat	Connector	Pillow	M6*20mm	M6*25mm	M8*20mm
M*10	N*1				
					
M6*16mm	Wrench				

Please note: Please check carefully if there are any missing parts before installation. If there are any missing parts, please place all the parts and take pictures then tell us the missing part number. We will reply you as soon as possible.

Assembly Instruction

5-Level Armrest Adjustment



To adjust downward: Push the armrest to the highest position, then firmly press inward and gently pull outward to the desired level.

To adjust upward: Simply lift the armrest gently to your preferred height.

Assembly Instruction

Chair Assembly

Step 7

I*1



Assembly Instruction

Chair Assembly


Step 1

M*10

A*5


B*5

C*1



Step 2

D*1




Assembly Instruction

Chair Assembly


Step 3

J*4
G*1
E*1



Step 4

K*4
H*1
F*1



Notice: don't tighten the screws completely.

2

Assembly Instruction

Chair Assembly


Step 5

G*1



Step 6

L*4
F*1



Please make sure the backrest is in the correct position, then tighten all the screws.

3